



CD 95/150 technikus menü





List of User Attributes

Te = Full Set	Aj = Unlock (& Output No.)
Re = Part Set / Partguard	Id = Time/Date (Log, Print)
Ki = Unset	Ke = Duress
Kz = Inhibit	Pr = Engineer Code
Bj = Walk/Bell/Chime Test	Fk = Light Control
Sk = Change Own Code	Kx = Manager
Kj = Change Other Code	Ah = Delay Timeclock

Key Attributes List

Gy = Quick Set
Te = Full Set
Re = Part Set
Ki = Unset
Im = Pulse

Zone Attributes List

Kz = Inhibit
Re = Partguard
Bj = Chime
24 = 24-Hour
2x = Double Knock
Bu = Access
Tu = Soak Test

List of Zone Types

betores
szabotazs
tamadas
elesito
tuz
kesleltetett1
kesleltetett2
fenykapcs.1
fenykapcs.2
napfeny erz.
veszkijarati
taphiba
muszaki
elesito kont
elesito nygb
ajtonyito
kezelo tilto
szabad

List of Output Types

kizaras	rendsNOK
elesitve	el.halszt
betores	el.elmrdt
tamadas	korai kik
tuz	techn.pr.
szabotazs	kuls.taph
tarol.vez	idopr.vez
muszaki	mozg.tszt
zummer	tuz torls
bels.szir	kik/rszt
kuls.szir	ajto+napl
fenykap.1	teszt vez
fenykap.2	musz+napl
ajtovez.	opt.kijlz
220V hiba	2.riaszt
reszeles	szabad

To the 'Misc' Menu

